



FITTING THE OAK CORD ADJUSTER
The oak cord adjuster allows you to adjust the height of the braided linen cord and adds an extra design detail.

1. Unscrew and separate one of the wooden buttons to expose the metal rod end.
2. Lift the bouquet to create a loop wherever you wish on the braid and hold in place.
- If you can, check the height of THE BOUQUET before you fit the other wooden button.**
3. Push the metal rod end through all layers of the braids and hold in place.
4. Screw the loose wooden button onto the metal rod until it is fastened onto the braid.

The size of the loop you make, determines the height of THE BOUQUET.

TILPASNING
Når lampen er hængt op kan skærmene flyttes rundt/justeres for at give det ønskede udtryk.
Lampen er monteret med en fletning på ca. 1,5 meter. Såfremt lampen skal hænges et sted med lavere loftshøjde benyttes den medfølgende tilbehørsdel.

1. Start med at skrue den ene træknapp af.
2. Fletningen vindes op med et loop.
3. Igennem de to lag fletninger skubbes metalstaven hvorefter træknappen monteres igen.
4. Loop'en kan gøres større eller mindre alt efter hvor højt lampen ønskes.

MODEL 130 3/5/7

Denne smukke moderne lysekrone
THE BOUQUET findes med både 3, 5 eller
7 skærme.

Designer Sinja Svarrer Damkjær er
inspireret af naturens forårsbebudere,
tulipanerne. De store bløde hoveder
som gør sig smukt i store buketter såvel
som i solitær form.

Ledningerne er valgt med en høroverflade
for at understrege tilknytningen til det
naturlige univers.

I lampeserien THE BOUQUET findes
desuden en pendel med en enkelt skærm.

This beautiful modern chandelier called
THE BOUQUET is available with either
three, five or seven lamp-shades.

Designer Sinja Svarrer Damkjær was so
inspired by how big beautiful soft tulip
petals, blossoms in the Spring. She even
symbolically detailed the flower stem, as
a braided linen covered electrical cord.

The series also includes a single pendant.



LE KLINT

Made in Odense, Denmark since 1943
Egestubben 13-17 · 5270 Odense N
leklint@leklint.dk · www.leklint.com

LE KLINT

Instruktion
Instructions Manual

Instruktion for Model 130 3/5/7

INDHOLD
THE BOUQUET Lysekrone med 3/5/7 skærme.
Flettet hørledning samt 3 meter hvid tilslutningsledning, monteret i en baldakin.

LYS
Anbefalet max. wattage:
130M3/5/7: LED-/Sparepære max. 10 W, E14
130L3/5/7: LED-/Sparepære max. 10 W, E27
130XL3/5/7: LED-/Sparepære max. 15 W, E27

NB: Ved for højt wattforbrug kan det give varmeproblemer i lampen og skærmen ødelægges.

VEDLIGEHOLDELSE
Ved evt. behov for rengøring inden i skærmen foregår afmontering på samme måde som ved montage af lyskilden. Skærmen holdes ren ved aftørring med blød klud eller støvbørste, f.eks. **LE KLINT DUST BUSTER**.

DETALJERNE
Da fletningen til hver lampe er lavet i hånden, vil der kunne opstå små varianter, det er en del af udtrykket. Fletningen giver mulighed for selv at arrangere skærmene som ønsket for at give præcis den buket man har lyst til i sit hjem.

UDPAKNING & MONTAGE
Alle pap-indlæg tages forsigtigt op af kassen. Løft alle skærme, samt ledning ud af indlæggene og stil/læg dem på en plan overflade.

Følg nedenstående instruktion for montage:

1. De flettede ledninger er monteret med en baldakin og 3 meter tilslutningsledning.
2. Montér passende pærer i alle fatninger.
3. Skærmen åbnes forsigtigt i toppen ved at skubbe/trække ud med fingrene. Den er lukket med en speciel elastik, så det er muligt at udvide den uden den springer.
4. Skub pæren, fatning og akrylskive ned i skærmen og lad den herefter lukke sig om trækeglen.
5. Gentag for alle 3, 5 eller 7 skærme.
6. Baldakinen sidder fast på bagpladen via 3 magneter.
7. Hold godt fast på baldakinen og træk i bagpladen i en af rillerne. Nu kan de to ting skilles ad.
8. Hvis ledningen skal trækkes ud til siden ved montage, skæres et af halvcirkel hullerne fri. Monter ledningen i el-udtaget nu hvis det sidder lige bagved baldakinen.
9. Montér bagpladen på loftet i minimum to af de fire huller tilgængelige.
10. Skub baldakinen på plads, sørg for den passer med de tre magneter og evt. lednings-udgangen.

NB: Baldakinen er ligeledes forberedt til direkte montage over el-udtag (LK loftsdåse), dette er gældende for det danske marked. Såfremt der er tvivl om fremgangsmåden, kontakt din autoriserede el installatør.

Instructions for Model 130 3/5/7

CONTENTS
THE BOUQUET Chandeliers - 3/5/7 lamp-shades.
Braided linen cord with 3 m white electric wire, within a canopy
Oak Cord Adjuster.

LIGHT
Light bulbs not included.
Maximum Recommended Wattage for Models:
130M3/5/7: LED-/CFL bulb max. 10 W, E14
130L3/5/7: LED-/CFL bulb max. 10 W, E27
130XL3/5/7: LED-/CFL bulb max. 15 W, E27

NB: If wattage is too high, heat from the light-bulbs can damage the lamp-shades.

MAINTENANCE
To clean the shades, you can use **LE KLINT DUST BUSTER**, a damp cloth or a soft brush.
To remove the shades - follow instructions 4 & 5 as you would fit or replace a lightbulb.

DETAILS
The braid for each lamp is handmade, so there will be some small inflections on the braid, which is part of the overall natural look of the complete design. The braid allows you the freedom to adjust each shade to your liking.

UNPACKING
Lift out and remove all contents within the packaging, from the box and lay on a flat surface eg: table top. Carefully remove the electrical linen braided wire and all shades from their individual packaging.
Please read through all instructions and carefully observe all photos, before you start to assemble your chandelier.

ASSEMBLY
We recommend that you fit the light bulbs and shades one at a time to avoid any breakages.

1. Unwind the braided cord then insert and fit a lightbulb into each socket.
2. Use your fingers on both hands to gently open and expand the top of the shade while holding the light bulb.
3. Carefully push the lightbulb, socket and clear acrylic ring, inside the shade and release. The shade will automatically close around the small wooden cone.
4. Repeat steps 1 – 3 to fit all 3,5 or 7 lamp shades.
5. Once all the lampshades are fitted, gather all to one side to prepare the canopy for the electric connection.

ELECTRICAL CONNECTION

NB: the white electric power cord can be attached to the electrical outlet, either directly through the centre of the acrylic plate or through the side hole of the canopy before connecting to the electrical outlet.

If in doubt please contact a qualified electrician.

6. The canopy is attached to the back plate via 3 magnets.
7. Hold the canopy firmly and pull on the back plate in one of the grooves. Now the two things can be separated.
8. If the cord is to be pulled out to the side during assembly, cut one of the semicircle holes free. Install the cord into the electrical outlet now if it is located just behind the canopy.
9. Mount the back plate to the ceiling in at least two of the four holes available.
10. Push the canopy into place, make sure it fits with the three magnets and the hole for the wire, if you chose to use that in the side.

