



CORD ADJUSTER

LE KLINT

A designer accessory
that is simple and
easy to use on
any lighting cord



Black Base
with Black



Black Base
with Brass



Black Base
with Aluminium



White Base
with White



White Base
with Brass



White Base
with Aluminium



LE KLINT Cord Adjuster

Place where ever
you like and get
light at any height



LE KLINT

www.leklint.com

MADE IN ODENSE, DENMARK



The Cord Adjuster must only be attached onto a cord that is already in use with a hanging pendant




1. Remove the Cord Adjuster from the packaging.



2. Place fingers on the edges then twist to unscrew and separate into two parts.



3. Place the part with the central hole to one side.




4. Place the part with the central screw and cut outs to your desired height on the electric cord and use your thumb to hold in place.




5. Use your other hand to loop the Cord Adjuster into the cut outs.




6. Use your fingers and thumb to hold cord in place inside the cut outs.



7. Attach the other side and screw until tightly fastened together.



8. **Please Note:** It is OK if some cord sizes do not allow the Cord Adjuster to close completely.



9. You can gently pull the cord to adjust the height of the pendant while the Cord Adjuster is attached.